




DALI Extender



# Installation instructions


Instructions d'installation  
Instrucciones de instalación

Istruzioni per l'installazione  
Installatie-instructies


Installationsanweisungen  
インストール手順

安裝指示书  
بەپەرستە تاداشرا


## Independent




## Built-in




## Independent




## Built-in




## 1 Independent




## Built-in



## 2 Surface mounting holes



## 4




**Caution**  
Never connect mains to any DA port, it damages the device.

**Note**  
Do not connect unsupported devices to DALI extender.

Implements and tested for IEC 62386-101:2022

## 3 Independent only



**Signify**

© 2023-2025 Signify Holding. All rights reserved. The information provided herein is subject to change, without notice. Signify does not give any representation or warranty as to the accuracy or completeness of the information included herein and shall not be liable for any action in reliance thereon. The information presented in this document is not intended as any commercial offer and does not form part of any quotation or contract, unless otherwise agreed by Signify. All trademarks are owned by Signify Holding or their respective owners.

UK importer address:  
Signify Commercial UK Limited  
2 Guildford Business Park  
GU2 8XG, UK